Back Cover

Lifeloc
TECHNOLOGIES

Premium Quality Breath Alcohol Testing Equipment
Since 1983

Hours of Operation:	7:30 am to 4:30 pm MST *If you are calling outside of these hours, please leave us a voice message.* *We will contact you the following business day!*
Address:	Lifeloc Technologies, Inc. 12441 West 49th Avenue, Suite #4, Wheat Ridge, CO 80033
Website:	www.lifeloc.com
Telephone:	303-431-9500
Toll free (US):	800-722-4872
Fax:	303-431-1423
Domestic Sales:	800-722-4872 or sales@lifeloc.com
International Sales:	+1-303-431-9500 or sales@lifeloc.com
Product Training & Certification:	800-722-4872 or training@lifeloc.com
Tech Support:	303-431-9500 or service@lifeloc.com
Other Inquiries:	800-722-4872

Lifeloc Technologies Inc. is located in Denver, Colorado, USA. Our
products are manufactured and serviced at this facility. To receive
a pricelist or brochure, or to find your nearest Distributor or Sales
Representative, please call the Lifeloc Sales Department.

Front Cover

Lifeloc
TECHNOLOGIES

FC20 Portable Breath Tester
Operations Manual

Lifeloc

TECHNOLOGIES

Premium Quality Breath Alcohol Testing Equipment

Since 1983

Wheat Ridge, Colorado

Table of Contents

Lifeloc
TECHNOLOGIES

Lifeloc
TECHNOLOGIES

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

ont>

To the FC20 Portable Breath Tester Operator:

Welcome!

The FC20 breath alcohol tester is manufactured in Denver, Colorado, by Lifeloc Technologies, Inc. Lifeloc offers premium quality products combined with exceptional service and technical support.

The FC20 is a state-of-the-art breath alcohol tester that is software based and incorporates unique cutting edge technologies. Because of the advanced FC20 design:

▸ Results on a positive test register in 10 seconds.

▸ You can take another test 30 seconds after a positive.

▸ Your FC20 will automatically take the test when it senses a deep lung sample is delivered.

▸ Your FC20 will provide an accurate test, or else explain to you why it cannot, and even provide suggestions on how to proceed to complete an accurate test on your subject.

▸ Your FC20 includes a host of other features: Calibration/ Calibration Check lock-out periods, Batch and Subject IDs, numerous printout options, passive testing, password protection (option) and more. All are explained in this manual.

The following pages will explain in detail the operation of your FC Series portable breath tester.

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

ont>

Front View

Front view
without
mouthpiece.

Front view with
mouthpiece
attached.

Mouthpiece
removal tab.

Standard Features

▼ **Large Graphic LCD Display,** capable of showing numbers, letters, icons, and plain-English text messages.

▼ **Automatic Calibration,** software controlled adjustments, no screwdriver or tools necessary.

▼ **Auto Test Mode,** the easiest, simplest way to take a test of any breath tester, Auto Test is fast, accurate, and virtually "hands-free".

▼ **On Board Memory,** stores the last 500 tests.

▼ **Real Time Clock,** stores time and date information with test results as well as calibration and cal check results.

▼ **Printer Ready,** print out any or all results using Lifeloc printers.

▼ **Adjustable Auto Shut-Off,** preserves battery life.

▼ **Passive Test Mode,** check for the presence of alcohol without using a mouthpiece.

▼ **Two Printout Options,** long or short.

▼ **Calibration Reminder with Lockout,** prevents you from using an FC20 when it is due for calibration.

▼ **User Selectable Test Order,** allows choice of either Auto Test or Passive Test default mode.

▼ **I.D. Entry,** capable of storing two separate I.D. numbers, one for subject and one for additional uses, operator, precinct, etc.

▼ **Fast Simple Operation,** while the FC20 contains a host of features, it is still easy to use.

ont>

Installing Batteries

Press in and down on the battery door located on the back of the FC20 in the direction of the arrow.

Install the four AA alkaline batteries in the direction of the symbols in the battery case.

Close the case by pushing up on the battery door until it locks shut.

Attaching a Mouthpiece

Remove the mouthpiece from its wrapper, making sure not to touch the end which the subject will be blowing into.

Attach the mouthpiece to the port on the back of the FC20.

Line up the mouthpiece port over the hole in the back of the mouthpiece. Press in place.

Ensure it is securely fit.

Turning the FC20 On and Off

To turn the unit on, press and hold the **Power** button on the bottom of the unit until it beeps. The FC20 performs an automatic internal diagnostics check.

To turn the unit off, press and hold the **Power** button until it beeps. The unit will shut down.

Note: Momentarily pressing the **Power** button, when the unit is on, will return you to the main menu. It will NOT save any changes to the settings you have made.

Observing the Subject

The FC20 provides a highly accurate reading of breath alcohol acquired by sampling deep lung air. However, the reading can be corrupted by residual mouth alcohol.

To prevent mouth alcohol from affecting a test, make certain that the subject is not allowed to put anything in their mouth for the 15 minutes prior to taking a test.

If the subject just took a drink, a 15 minute observation period in which they are not permitted to put anything in their mouth should be observed before testing. This will ensure all residual alcohol from any source is completely dissipated and test results will be valid.

4

Taking an Auto Test

Attach the mouthpiece to the back of the unit.

Verify the display reads "AUTO TEST".

Instruct subject to blow into the mouthpiece **firmly and steadily for as long as they can.** (Not necessarily as hard as they can).

Read the result.

After taking a test the FC20 will display the result in large numbers on the display.

Additionally, the result is stored in memory and available for viewing at a later date.

Press the **Function** button to return to the test mode.

www.Lifeloc.com   **Lifeloc** TECHNOLOGIES   800-722-4872

Breath Flow

As the subject blows into the mouthpiece, the FC20 will show a graph of the breath flow on the display.

Alcohol Curve

If the FC20 detects alcohol, the alcohol level is graphed and will be displayed before the result.

www.Lifeloc.com   **Lifeloc** TECHNOLOGIES   800-722-4872

Test Result

After the alcohol is graphed, the test result is displayed.

The result will remain on the screen for 90 seconds, or until the **Function** or **Power** button is pressed, or the test is printed.

Removing the Mouthpiece

Remove the mouthpiece by pushing against the back of the tab located on the exhaust end.

Viewing the Previous Test Results

Press the **Function** button repeatedly until the printer icon is displayed. The results of the last test will be displayed along with its test number at the lower left of the display.

The FC20 retains up to 500 tests along with all related data in memory.

Press the **+** or **–** buttons to view previous tests.

Press the **Function** button repeatedly to return to the testing mode.

Printing Test Results

Printing the Current Test

Take a test.

Plug the printer cable into the connector on the side of the FC20.

Press the **Execute** button, under the printer icon.

Printing a Specific Test

Press the **Function** button repeatedly until the printer icon is displayed.

Press the **+** or **–** button to select the test number you wish to print.

Press the **Execute** button, under the printer icon, and the printer will activate.

Printing All Stored Tests

Press the **Function** button repeatedly until the printer icon is displayed.

Press the **+** or **–** button to select 'ALL.'

Press the **Execute** button, under the printer icon, and the printer will activate.

Breath Testing Modes Explained

The FC20 is capable of conducting three distinct types of breath tests.

▶ **Automatic Test** is the most used and highest accuracy test. The FC20 monitors the subject's breath and automatically takes the sample near the end of the breath flow.

▶ **Manual Test** is normally used only when the subject is unable to provide a sufficient air sample for the automatic test.

▶ **Passive Test** is a quick screen to detect alcohol but is not designed to quantify the results. Passive results are reported as POS if alcohol is detected, NEG if alcohol is not detected. In this mode, no mouthpiece is required. reported as "POS" if alcohol is detected, "NEG" if alcohol is not detected. In this mode, no mouthpiece is required.

Conducting an Automatic Test

Turn the FC20 on.

Attach a mouthpiece to the back of the unit.

Verify the display reads "AUTO TEST".

Instruct subject to blow into the mouthpiece **firmly and steadily for as long as they can.** (Not necessarily as hard as they can).

Read the result.

Conducting a Manual Test

Turn the FC20 on.

Attach a mouthpiece to the back of the unit.

Press the **Function** button until the display reads "MANUAL TEST".

Instruct the subject to blow into the mouthpiece **firmly and steadily for as long as they can.**

When they are near the end of their breath, press the **Execute** button.

Read the result.

Manually Overriding an Automatic Test

Note: This feature allows the completion of a test in the occasional instance when the subject may have diminished lung capacity and cannot activate the Auto Test.

Turn the FC20 on.

Attach a mouthpiece to the back of the unit and verify the display reads "AUTO TEST".

Instruct the subject to blow into the mouthpiece **firmly and steadily for as long as they can.**

When they are near the end of their breath, press the **Execute** button.

Read the result.

ont>

Conducting a Passive Test
(No mouthpiece)

Turn the FC20 on.

Press the **Function** button until the display reads "PASSIVE TEST".

To take the test:

Hold the FC20 sample port (orange-colored opening labeled "Port" on the back label of the FC20) about four inches from the subject's mouth.

Have the subject blow towards the port.

Press the **Execute** button while the subject is blowing.

Read the result. ("POS" or "NEG")

Summary

Now that you have been through the first part of this manual, you know everything necessary to begin using your FC20. You are capable of conducting Auto, Manual and Passive tests with ease… but that's not the entire story.

The following pages will guide you through the additional user-selectable settings available in this state-of-the-art instrument. We highly recommend you look these over and see if they can improve the efficiency and ease-of-use of your FC20 breath alcohol tester by customizing it to your particular situation.

After looking over the settings you will want to proceed to the Calibration and Maintenance section. There, we will take you through step-by-step processes for calibration of your FC20 and make maintenance recommendations, to keep your unit functional for years of trouble-free use.

Finally, in the warranty and service section, you can find the details of your FC20 factory warranty, and information on service and high quality supplies available through Lifeloc Technologies.

Fast, accurate, and easy to use, the FC20 breath alcohol tester is a premium quality, precision, state-of-the-art breath alcohol tester, designed for professional use.

ont>

The Settings Chart

Lifeloc
TECHNOLOGIES

The Settings Screen

The FC20 has numerous internal settings allowing you to customize the unit to your individual needs. The settings include the following:

Time

Date

Auto Air Blank (If installed see page 33-34)

Auto Shut-Off Time (1 – 15 minutes or "Off")

I.D. Settings

　Batch ID

　User + Batch ID

Trigger Mode

　End of Breath

　Precise Volume

Security (If installed see page 32-33)

Print Settings

　Number of copies printed (1, 2 or 3)

　Print Format (Long or Short)

　Printer selection

Display Settings

　LCD Contrast

　Test Order

　Results Format

　Pass & Fail Level Settings

Exit

Lifeloc
TECHNOLOGIES

4

The Settings Screen

Press the **Function** button repeatedly until display reads "SETTINGS".

Press the **Execute** button once.

Pressing the **Function** button repeatedly scrolls you through the FC20 user settings.

Changing The Time

From the "Settings" display, press the **Execute** button.
The display will now read "Time" with the hours digits flashing.

Press the **+** or **–** buttons to change the hour.

Press the **Execute** button to move to minutes.

Press the **+** or **–** buttons to change the minutes.

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Changing the Date

From the "Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "Date".

Press the **+** or **–** buttons to change the year.

Press the **Execute** button to move to the month setting.

Press the **+** or **–** buttons to change the month.

Press the **Execute** button to move to the day.

Press the **+** or **–** button to change the day.

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

ont>

Automatic Air Blank (Option)

Auto Air Blank is a factory option available on the FC20.

If you have this option installed, refer to page 34 of this manual for instructions on set-up and use.

Setting the Auto Shutoff Time

From the "Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "Shutoff Time".

Press the **+** or **-** buttons to adjust the shutoff time between 1-15 minutes or disable auto shutoff by selecting "0".

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

---

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

I.D. Entry Explained

The FC20 allows you to enter two different I.D. numbers and/or names: the Operator (Batch I.D.) and the Subject (Subject I.D.).

The **Batch I.D.** remains the same once entered, until changed again. If entered, it is stored and printed out with every test result.

The **Subject I.D.** is unique to each test. If turned on, you will be prompted to enter a Subject I.D. every time you take a test. The Subject I.D. will be stored and printed out with the test result.

Entering a Batch I.D.

From the "Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "I.D. Setting".

Press the **Execute** button to select either "Subject + Batch" or "Batch", then press the **Function** button once. The display will read "Batch I.D."

Press the **+** or **-** buttons to enter numbers/letters of the I.D you wish to enter (hold down to scroll quickly).

Press the **Execute** button to move to the next digit. Up to 16 characters may be entered.

Press the **Function** button to save the changes and return to the testing mode.

---

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

Entering a Subject I.D.

From the "Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "I.D. Setting".

Press the **Execute** button to select "Subject + Batch", then press the **Function** button once. The display will read "Batch I.D."

Press the **+** or **–** buttons to enter numbers/letters of the Batch I.D. (hold down to scroll quickly).

Press the **Execute** button to move to the next digit. Up to 16 characters may be entered.

Press the **Function** button to save the changes and return to the testing mode.

The FC20 will now prompt you to enter a Subject I.D. before every test.

Use the **+** or **–** buttons to enter numbers/letters (hold down to scroll quickly).

Press the **Execute** button to move to the next digit. Up to 16 characters may be entered.

Press the **Function** button to proceed to take a test. The Subject I.D. will be stored and printed with the next test taken.

To by-pass entering a Subject I.D., simply press the **Function** button and take a test.

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

Trigger Mode

From the "Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "Trigger Mode".

Press the **Execute** button to select between "End of Breath" and "Precise Volume".

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Security Settings (Option)

The password option is a factory installed option that allows the FC20 administrators to prevent field personnel from performing any change to the FC20 user settings or from performing a calibration or cal check.

For more information regarding the use of this option, refer to page 32 of this manual for instructions on set-up and use.

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

ont>

Print Settings Explained

The FC20 settings allow you to customize your printout to your particular needs. You can choose between the following:

Number of Copies - Choose to print 1, 2 or 3 copies of a test when you print.

Print Format - Choose to include or not to include the calibration and calibration check information with every printout by selecting the long or short format.

Printer - Select between the "AP892", "DP1014", "DataTrak", or "Other" to print your results.

Number of Copies Printed

From the "Print Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "Number of Copies".

Press the **+** or **-** buttons to change the number of copies printed to 1, 2 or 3.

Press the **Function** button to move to the next setting or repeatedly until the display reads Exit.

Press the **Execute** button to save the changes and return to the testing mode.

Print Format

From the "Print Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "Print Format".

Press the **Execute** button to select "Long" or "Short" printouts.

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Printer Selection

Printer selection allows you to select what device your FC20 will communicate with.

From the "Print Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "Printer".

Press the **Execute** button to select between the Lifeloc "AP892" printer, "DP1014" printer, "DataTrak" computer based download software or "Other" printer.

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

4

Sample Print-outs

Long Printout

```
Lifeloc Technologies, Inc.
          FC20
         v6.00
Serial No.      01080
Units:          BAC
AUTO TEST #     857
Result:         .101
Time:           09:53
Date:           12/12/2005
Last Calibrated:
Cal Standard:   .040
Time:           07:47
Date:           5/11/2005
Last Check:
Cal Standard:   .040
Result:         .040
Time:           11.25
Date:           5/11/2005

Subject _____

I.D. _____

Operator _____
```

Short Printout

```
Lifeloc Technologies, Inc.
          FC20
         v6.00
Serial No.      01080
Units:          BAC
AUTO TEST #     857
Result:         .101
Time:           15.26
Date:           05/20/2005

Subject _____

I.D. _____

Operator _____
```

Cal/Cal Ck Printout

```
Lifeloc Technologies, Inc.
          FC20
         v6.00
Serial No.      01080
Units:          BAC
Last Calibrated:
Cal Standard:   .040
Time:           07:47
Date:           02/11/2005
Last Check:
Cal Standard:   .040
Result:         .040
Time:           15.26
Date:           02/14/2005
```

www.Lifeloc.com **Lifeloc TECHNOLOGIES** 800-722-4872

Display Contrast

From the "Display Settings" screen press the **Execute** button.

Press the **Function** button until the display reads "LCD Contrast".

Press the + or - buttons to set the contrast to the desired level.

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Test Order Sequence

From the "Display Settings" screen, press the **Execute** button.

Press the **Function** button until the display reads "Test Order".

Press the **Execute** button to choose between "Auto" or "Passive" testing as the default when you turn the unit on.

Press the **Function** button to move to the next setting or repeatedly until the display reads Exit.

Press the **Execute** button to save the changes and return to the testing mode.

Test Order 1
Auto Test (Default)
Manual Test
Passive Test

Test Order 2
Passive Test (Default)
Auto Test
Manual Test

www.Lifeloc.com **Lifeloc TECHNOLOGIES** 800-722-4872

4

ont>

Results Format Explained

The FC20 displays Auto Test and Manual Test results in a 3 digit BAC format. Passive test results are displayed as POS or NEG.

If however, you are simply trying to qualify whether the subject is within "set" limits, you may not need a quantitative result. Especially if the user is not trained in understanding BAC levels (such as teachers at a high-school dance testing juveniles).

In this instance, you may choose to have the FC20 display the results as PASS, WARN, or FAIL (PWF mode).

PASS

FAIL

Setting Results Format (Pass/Warn/Fail)

From the "Display Settings" screen, press the **Execute** button.

Press the **Function** button repeatedly until the display reads "Results Format".

Press **Execute** button, to toggle between "Numeric" or "PWF".

Press the **Function** button until the display reads "Pass Level".

Press + or – button to set the BAC Pass level (eg., .005).

Press the **Function** button until the display reads "Fail Level".

Press + or – button to set the BAC Fail level (eg., .040).

Press the **Function** button until the display reads "Exit".

Press the **Execute** button to save and return to the testing mode.

NOTE: You cannot set the PASS level higher than the FAIL level. An alcohol reading higher than the PASS level and lower than the FAIL level will read WARN.

4

Factory Options Explained

The FC20 has extended features that can be ordered from the factory. These are not standard on the unit but only available as special order items.

The available factory options include Password Protection, Auto Air Blank and Automatic Altitude Compensation for use with dry gas standards.

Contact Lifeloc Technologies for further information on FC20 factory options.

Password Protection Explained

If installed, this option limits field personnel to basic breath testing tasks such as taking tests and printing results.

Without a password, operators will not be able to change any settings or calibrate/cal check the unit.

Note: *Failure to remember your password will require that the FC20 be sent back to Lifeloc to re-initialize the password.*

www.Lifeloc.com

Lifeloc
TECHNOLOGIES

800-722-4872

Setting Password Protection

From the "Settings" screen, press the **Execute** button. The display will read "Time".

Press the **Function** button until the display reads "Security Settings".

Press the **Execute** button. The unit is now ready to accept a password. Use the **+** or **-** buttons to enter a number or letter.

Use the **Execute** button to move to the next digit or press the **Function** button repeatedly until the display reads "EXIT".

Press the **Execute** button to return to the testing mode.

Auto Air Blank Explained

If installed, this option inserts an automatic air blank function in front of Auto, Manual, and Passive tests.

An automatic air blank is a test of the ambient air. It checks to ensure that no alcohol is present, which could affect the test result.

If Auto Air Blank is enabled, the FC20 will prompt you to take a sample before testing the subject.

Auto Air Blank is normally utilized to satisfy the requirements of a specific testing protocol.

www.Lifeloc.com

Lifeloc
TECHNOLOGIES

800-722-4872

4

ont>

Setting the Auto Air Blank

From the "Settings" display, press the **Execute** button.

Press the **Function** button until the display reads "Auto Air Blank."

Press the **Execute** button to turn the air blank "On" or "Off".

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Automatic Altitude Compensation

The FC20 may be purchased with a fully integrated automatic barometric pressure sensor installed.

This sensor greatly simplifies calibration with dry gas standards by automatically adjusting for the effects of altitude.

Calibration Explained

Calibration of an FC20 compares its internal settings to a known alcohol standard, thereby providing it with the baseline from which it can accurately calculate the subject's alcohol level.

You can use most available BAC levels of gas or solution to calibrate your FC20, however, most commonly used are: .100, .080 or .040 BAC.

The FC20 must be between 67° and 100° to calibrate. (19° - 37° C)

Lifeloc recommends you calibrate your FC20:

Once every 12 months, regardless of how many tests you have performed;

OR, after two failed Calibration Checks;

OR, at intervals specified by your Internal Policies, Quality Assurance Plan, or State Regulations.

A Calibration Check simply verifies the FC20 was calibrated correctly and is within the acceptable accuracy range. (Commonly called "External Calibration Check," "Accuracy Check," "Cal Check," or "Verification").

Lifeloc recommends you check your FC20:

Once every 30 days;

OR, at intervals specified by your Internal Policies, Quality Assurance Plan, or State Regulations.

ont>

Calibration Explained

There are two types of Calibration/Calibration Check methods:

Wet Bath Simulator

Dry Gas

You can calibrate and check your FC20 using either method. However, you must **first** set your FC20 to recognize which method, or which "Standard Type" you will be using.

Once you choose the standard type, the FC20 will store that information in memory. You do not have to set it again unless you change to a different method of performing a calibration/calibration check.

Dry Gas Calibration requires that you enter the corrected Standard Value before calibration, based on your altitude or elevation. Using the chart on the outside of the canister, multiply the number next to your elevation by the standard. **Example:** Denver Colorado elevation 5280 Ft. above sea level. Correction factor .820 x .100 = .082 corrected standard.

If you move to a location at a significantly different altitude, you will have to change the standard in the FC20.

Note: The FC20 comes from the factory set for wet bath simulator and a .100 solution standard.

Calibration Display Chart

CALIBRATION
→ Execute → XXX CHECK
→ Execute → Perform a Cal Check
→ Function → XXX CALIBRATE
→ Execute → Perform a Calibration
→ Function → CAL SETTINGS
→ Execute → Cal Standard
→ Function → Standard Type
→ Function → Cal Period
→ Function → Check Period
→ Function → EXIT
→ Function → EXIT

4

Setting the Calibration Standard

From the "CALIBRATION" display, press the **Execute** button. The display now reads "XXX CHECK".

Press the **Function** button until the display reads "CAL SETTINGS".

Press the **Execute** button and the display will read "Cal Standard".

Use the **+** and **–** buttons to change the number to the BAC level of standard you will be calibrating to (it should be the same as on the bottle of certified solution or your corrected standard if using a dry gas tank).

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Once you set the standard you do not have to set it again unless you change to a different method of performing a calibration/calibration check.

Cal Standard
.100

Setting the Standard Type

From the "CAL SETTINGS" display, press the **Execute** button.

Press the **Function** button until the display reads "Standard Type XXX XXX".

Press the **Execute** button to choose between "Dry Gas" and "Wet Bath".

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Calibration/Cal Check Lock-Out Explained

The calibration/cal check lock-out allows you to prevent usage of your FC20 if it is not calibrated or cal checked in a specified time period.

Beginning 48 hours before the specified lock-out time, the unit will display "WARNING CAL EXPIRING", "WARNING CHECK EXPIRING" or both.

When the time period has elapsed, the unit will display "CAL EXPIRED", "CHECK EXPIRED" or both and not allow testing until it is calibrated/cal checked.

You can specify time periods up to 999 days between calibrations or cal checks.

Setting the Calibration Lock-out Period

From the "CAL SETTINGS" display, press the **Execute** button.

Press the **Function** button until the display reads "Cal Period XXX".

Press the **+** or **–** buttons to enter the number of days until you require the next calibration of your FC20. Choosing "Disabled" turns this setting off. (

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Setting the Calibration Check Lock-out

From the "CAL SETTINGS" display, press the **Execute** button.

Press the **Function** button until the display reads "Check Period XXX".

Press the **+** or **–** buttons to enter the number of days until you require the next cal check of your FC20. Choosing "Disabled" turns this setting off.

Press the **Function** button to move to the next setting or repeatedly until the display reads "Exit".

Press the **Execute** button to save the changes and return to the testing mode.

Simulator Set-up

Pour a bottle of certified Alcohol Solution into the simulator jar, tighten lid securely.

Turn on the simulator.

The simulator automatically heats the solution to 34°C.

Attach a mouthpiece adapter securely to the outlet port on the simulator lid.

ont>

4

ont>

Calibration (Simulator)

Turn the FC20 on. Attach a mouthpiece to the back of the unit.

Verify the "Cal Standard" is set to the concentration you will be using when you calibrate.

Verify the "Standard Type" is set to "Wet Bath".

Press **Function** button until display reads "CALIBRATION", then press the **Execute** button.

Press **Function** button until display reads "WET CALIBRATE".

Slide the FC20 mouthpiece over the other end of the adapter.

Blow through the input tube (or use a calibration pump) to create 1/2" bubbles on the surface of the solution.

After three seconds of blowing, press the **Execute** button to take the sample, while continuing to blow for another three seconds.

Stop blowing.

If successful, the display will read "CAL COMPLETE".

Disconnect the equipment and wait two minutes before conducting a Cal Check.

Note: Following Calibration it is required that you perform a Calibration Check.

www.Lifeloc.com   **Lifeloc** TECHNOLOGIES   800-722-4872

Calibration Check (Wet Check)

Turn the FC20 on. Attach a mouthpiece to the back of the unit.

Verify the "Standard Type" is set to "Wet Bath".

Press **Function** button until display reads "CALIBRATION".

Press **Execute** button. The display will read "WET Check".

Slide the FC20 mouthpiece over the mouthpiece adapter.

Blow through the input tube (or use a calibration pump) to create 1/2" bubbles on the surface of the solution.

After three seconds of blowing, press the **Execute** button to take the sample, while continuing to blow for another three seconds.

Stop blowing.

Read the result. It should be within +/- .005 BAC of the standard used.

Example: a .100 BAC solution should read between .095 and .105 BAC.

www.Lifeloc.com   **Lifeloc** TECHNOLOGIES   800-722-4872

ont>

Dry Gas Set-up

Screw the regulator onto the dry gas tank.

Attach the mouthpiece adapter to the outlet port on the regulator.

Note: Do not store the dry gas tank with the regulator attached. The regulator is not designed as the primary sealing mechanism and your dry gas may leak from the tank.

Calibration (Dry Gas)

Before calibrating, verify the "Calibration Standard" is set correctly and the "Standard Type" is set to "Dry Gas".

Turn FC20 on. Attach a mouthpiece to the back of the unit.

Press **Function** button until display reads "CALIBRATION".

Press **Execute** button. The display will read "DRY CHECK".

Press **Function** button until display reads "DRY CALIBRATE".

Verify the Standard matches your corrected standard value.

Attach the FC20 mouthpiece to the regulator by sliding it over the mouthpiece adapter, ensuring a snug fit.

Press and hold down the regulator button to deliver a gas sample.

After the gas flows for three seconds, press and release the **Execute** button to take the sample.

After three more seconds, release the valve button to discontinue the flow of gas from the tank.

If successful, the display will read "CAL COMPLETE".

Disconnect the equipment and wait two minutes before conducting a Calibration Check.

Note: Following Calibration it is required that you perform a Calibration Check.

Calibration Check (Dry-Check)

Verify the "Standard Type" is set to "Dry Gas".

Turn FC20 on. Attach a mouthpiece to the back of the unit.

Press **Function** button until display reads "CALIBRATION".

Press **Execute** button. The display will read "DRY CHECK".

Attach the FC20 mouthpiece to the regulator by sliding it over the mouthpiece adapter, ensuring a snug fit.

Press and hold down the regulator button to deliver a gas sample.

After the gas flows for three seconds, press and release the **Execute** button to take the sample.

After three more seconds release the regulator button to discontinue the flow of gas from the tank.

The display will read a result that should be within +/-.005 BAC of the standard (if .100 BAC or less).

Check your result against the corrected standard.

Fuel Cells

Fuel cells are highly durable sensors that are capable of providing accurate breath alcohol results for years. There are however, a few precautions you should take to make certain that these devices perform for the longest period of time possible.

Use the device. Fuel cells like moisture. It is a good idea to take tests periodically to provide needed moisture to the fuel cell, especially in dry climates. You do not need alcohol, just breath.

Avoid cigarette smoke. Make certain no one is permitted to blow cigarette smoke into the unit. This can damage the fuel cell quickly.

Cleaning

Use of a mild disinfectant cleaner and a soft cloth on the outside of the case is recommended periodically to keep your unit clean. Do not use alcohol to clean the unit.

Batteries

The four AA batteries in your FC20 should last for about 160 hours of "on" time which can equate to as many as 6000 to 8000 tests. It is recommended you use high-quality alkaline batteries with your unit.

ont>

DataTrak™ Explained

DataTrak™ is a software program developed by Lifeloc, exclusively for use with Lifeloc's breath testing equipment. Ordered separately, DataTrak software enhances the capabilities of the FC20 by allowing it to communicate with a computer and comes complete with CD, cable and instructions.

Data Download, with DataTrak you can download any or all of the tests stored in the FC20 in a comma delimited text format for easy import into most spreadsheet or database programs.

Printout, with DataTrak and your computer you can print the results of any test result stored in the FC20.

Remote Troubleshooting, with just a click of a button, DataTrak can download critical operation parameters of the FC20. This information can then be e-mailed or sent to Lifeloc Technical support for analysis.

DataTrak Set-up

Connect the FC20 to the serial port on the PC, using the FC20 computer cable supplied with DataTrak software.

From the "PRINTER" screen choose the DataTrak option.

Refer to the DataTrak Operations Manual to establish communication with the FC20.

www.Lifeloc.com — **Lifeloc** TECHNOLOGIES — 800-722-4872

www.Lifeloc.com — **Lifeloc** TECHNOLOGIES — 800-722-4872

USER PROMPT	COURSE OF ACTION
Flow Error Retry & Blow Steadily	Exhalation not complete or interrupted. Instruct subject to blow steadily as long as they can.
<1.3L Retest or Try Manual Test	Breath flow ended before the subject blew 1.3 liters of breath. Instruct subject to try again or use manual test mode. Press the Function button to continue.
Excessive Alcohol	Too much alcohol for the unit to measure.
Timeout	Try again. If this problem persists contact Lifeloc support.
Temperature	When taking a test, calibrating or performing a cal check, unit is outside of temperature limits.
Low Battery	Battery voltage is too low to take a test. Replace batteries.
Low Li Battery	The internal clock battery is low. Contact Lifeloc support.
Pump Reset Needed	The pump needs reset. Restart unit or follow screen instructions. If this problem persists, contact Lifeloc support.
External Interference	External interference (such as RF noise) has been detected. Try to move to a different location and try again.
Calibration / Cal Check Expiring	The unit is within 48 hours of the Calibration or Cal Check lockout time. Calibrate or Cal Check the unit.
Calibration / Cal Check Expired	Calibrate or Cal Check the unit.
Printer Error	Check that printer is connected and power is on.
Wait	Wait for next prompt.

4

Factory Limited Warranty on New Units

The FC20 comes with a one year limited parts and labor warranty, effective on the date of purchase by the end-user.

The Warranty covers:

Parts and labor on covered repairs.

Software updates as applicable.

Airfreight back to the customer after the unit is repaired (U.S. only).

The Warranty does not cover:

Freight to the Lifeloc factory.

Misuse, abuse, negligence or accidents.

Extended Service Plans

Extended service plans are available for your FC20. These provide complete coverage for an additional year at a reasonable cost and include free Factory Diagnostic Checks. Call Lifeloc for additional details, or apply online.

Service

If your FC20 should require repairs or maintenance, Lifeloc is there for you. Just an email or phone call will put you in contact with our technical support personnel.

Lifeloc typically repairs units within four working days from the time it is received.

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

Notice

The FC20 is a professional device designed to be used by trained operators in conjunction with a specified, periodic maintenance and calibration/calibration check regimen. Use by untrained operators or without periodic calibration or calibration checks, may result in invalid results or incorrect interpretation of results.

DO NOT DRINK AND DRIVE. Lifeloc strongly recommends that no vehicle be operated after alcohol consumption. Even small quantities of alcohol can result in driving impairment.

Supplies

Visit www.lifeloc.com or call 303-431-9500 to purchase supplies.

Disposables
• Mouthpieces
• Batteries, four quality AA alkaline, source locally

Calibration
• Wet bath simulator and solutions
• Dry gas tanks and regulators

www.Lifeloc.com

Lifeloc TECHNOLOGIES

800-722-4872

Lifeloc
TECHNOLOGIES

Premium Quality Breath Alcohol Testing Equipment
Since 1983

Wheat Ridge, Colorado