# Section Five Quality Assurance

#### 5.2 **Balance Calibration and Intermediate Checks**

### 5.2.1 **BACKGROUND**

Refer to manufacturer's manual for balance specific procedures.

#### 5.2.2 **SCOPE**

The procedure is to ensure accuracy of measurement when an analytical or toploading balance is used to prepare solutions or reference material for application to toxicology methods.

#### 5.2.3 **EQUIPMENT**

- ANSI/ASTM Type I, Class 1 or Class 2 laboratory weights 5.2.1.3.1
- and/or Top-Loading, Direct-Reading Laboratory 5.2.1.3.2 Analytical Balances

### 5.2.4 **QUALITY ASSURANCE REQUIREMENTS**

- 5.2.4.1 All balances will be calibrated and serviced yearly by a qualified vendor.
- 5.2.4.2 Weights used for intermediate checks of calibration will be calibrated yearly by a qualified vendor.
- An in-house intermediate check of balances in use will be performed on a monthly basis. Results are to be recorded in logbook. Balances not in-use need not be checked, however, the balance must then be checked prior to use.
- The weights used for the intermediate check should depend on the application of the balance. Three weights must be used to represent the weight range in question. For instance, if the balance is being used to prepare buffer solutions, then perhaps 100g, 500g and 1000g weights would characterize the weight range. If the balance is used to prepare mg/mL reference material then 1mg, 10mg and 100mg/mL weights may be appropriate.
- 5.2.4.5 The type of balance employed should be a consideration. For weights less than 100mg, an analytical balance should be used. For the preparation of a solution involving gram quantities, a toploading balance should be used.

Issuing Authority: Quality Manager

5.2.4.6 Do not touch weights with bare hands. Weights should be transferred with forceps or gloves.

### 5.2.5 GENERAL PROCEDURES

- 5.2.5.1 Inspect balance pan, clean if necessary.
- 5.2.5.2 Inspect level bubble, level if necessary.
- 5.2.5.3 Tare balance with weighing paper.
- 5.2.5.4 Place weight on balance.
- 5.2.5.5 If appropriate, add or subtract correction factor for weight as determined by yearly weight calibration certificates.
- 5.2.5.6 Record corrected weight on balance logsheet.
- 5.2.5.7 The acceptable range for the balance is based on whether an analytical or top-loading balance is used.

5.2.5.7.1 Analytical Balance

Weight	Tolerance	Acceptable Range
100mg	±1.0mg	99.0mg - 101.0g
(0.1g)	(0.001g)	
100g	±0.1g	99.9g - 100.1g

# 5.2.5.7.2 <u>Top-loading Balance</u>

Weight	Tolerance	Acceptable Range
10.00g	±0.02g	9.98g - 10.02g
100.00g	±0.2g	99.8g - 100.2g
500g	±0.5g	499.5g - 500.5g
1000g	±1.0g	999.0g - 1001.0g

5.2.5.8 The verification procedure should be repeated if the corrected value does not fall within the acceptable range. If value is still out of range, contact service vendor to set up a service call. A note must be placed on the balance to indicate that it is not in range and must not be used.

### 5.2.6 REFERENCES

5.2.6.1 ASTM Method E-617-97, **Standard Specification for Laboratory Weights and Precision Mass Standards.** 

2 of 3

Rev. 2

Issued: 05-07-2007

5.2 – Balance Calibration Requirements – Rev 2.doc

Issuing Authority: Quality Manager

# Revision History

# Section Five Quality Assurance

### 5.2 Balance Calibration and Intermediate Checks

1 09-18-01 Original Issue	5
2 05-07-2007 Updated QA measures and reforma based on current requirements.	tting
colic wer on	
*6/Uje,CH	
Ctalled IMIL	
No *tolloco	
of Idaho of the Police het only of Idaho of	
101 Justille	
ekty coll	
0.000	